Faster Hardware, Smarter Code
Optimizing X for Graphics Accelerators

Todd Newman

Digital Equipment Corporation
Workstation Systems Engineering
Palo Alto, CA 94301

ABSTRACT

Graphics accelerators are necessary to achieve acceptable performance for certain graphics operations like 3D hidden surface removal or image convolution. They can also boost simple 2D operations for key applications. But they add substantially to the cost of a workstation. This paper discusses techniques for obtaining the maximum performance from a graphics accelerator, some general principles to use in planning optimization, and some specific tricks for squeezing out the last drop of speed.

Introduction

Everyone wants their workstation to run infinitely fast and cost nothing. Since we live in a less than perfect world, systems designers must balance the performance of a system, which can be improved by adding special purpose hardware, against the price of the system, which can be improved by removing hardware. For applications that are not graphics intensive, like CASE, the optimum solution seems to be to just provide a block of memory which the display system will show as a rectangular array of pixels. For certain graphics operations like 3D hidden surface removal or image convolution, graphics accelerators are necessary to achieve acceptable performance. They also may boost performance on simple 2D operations for key applications. Offloading rendering work to a graphics accelerator leaves more CPU cycles for all applications. So graphics accelerators can be a big win. On the other hand, they can add substantially to the cost of a workstation. If you decide to add one, you want to be sure to get the full benefit from it. This paper discusses techniques for obtaining the maximum performance from a graphics accelerator. It discusses some general principles to use in planning optimization and some specific tricks for squeezing out the last drop of speed. Digital workstations are used as examples, but the guidelines suggested should work on any workstation.[1]

Types of Graphics Systems

The simplest graphics system is built by adding memory that gets scanned out to a display. The block of memory is called the frame buffer. The CPU sees it as just some I/O space memory. The video subsystem sees it as a rectangular array of pixels. For example, our CX board has 884,736 bytes of memory on it that the CPU sees at some memory location, call it FrameBufferBase, determined at run time. The video subsystem sees it as 1024x864 8 bit deep pixels. When the CPU writes a byte at the address FrameBufferBase + 1024 + 10, it changes the tenth pixel in the second row of the screen. Systems with frame buffers more than one bit deep are called Color Frame Buffers (CFBs).

Color frame buffers are great — up to a point. Because all the functionality is in software, they're flexible, easy to optimize, and the code is quite portable. But they're very CPU intensive. Furthermore, their rendering rates degrade noticeably on large area primitives. (See Table 1) This is simply because they access memory in roughly constant time, so performance degradation asymptotically approaches being

[1] And, of course, you don't need to apply them to Digital's workstations, because we've already done it for you.

linearly with area.[2] Performance is also a function of the number of bits in a pixel. Eight bit pixels packed four to a word are roughly four times faster than 24 bit pixels packed one to a word.

Performance degradation with increase in area	
rate per second	operation
180000	1x1 rectangle
81800	10x10 rectangle
2130	100x100 rectangle
89	500x500 rectangle

Table 1.

If we want a graphics system that runs any faster than that, we build some kind of hardware graphics accelerator. For the purposes of this paper, that's all I mean by a graphics accelerator -- that it makes something run faster than a CFB would. Most graphics accelerators are interposed between the CPU and the framebuffer. Usually they have some privileged access to the framebuffer that the CPU does not. For example, on Digital's PixelStamp graphics system each stamp chip accesses five pixels in parallel. And one could gang together up to four stamp chips in a system allowing access to 20 pixels at once. This parallelism accelerates many primitives. (See Table 2.) The price for this performance gain is that the CPU cannot directly access the framebuffer, but must make special requests through the PixelStamp. None of the MIT-provided CFB code could be used. We had to rewrite everything, but many primitives ran much faster than the CFB code ever could.

Performance acceleration with graphics engines		
CFB	PixelStamp	Operation
180000	139000	1x1 rectangle
81800	139000	10x10 rectangle
2130	13500	100x100 rectangle
89	585	500x500 rectangle
1020	13500	100x100 stippled rectangle
84	585	500x500 stippled rectangle
119000	190000	10-pixel line segment
156000	319000	10-pixel line
27600	100000	100-pixel line

Table 2. (measured with x11perf on DS5000/200 CX "CFB", PXGTurbo "PixelStamp")

All the graphics accelerators I've seen come in one of two variants. One sort has a set of registers that you load and then a final one that kicks off the operation. The other sort interprets a command packet which resides in memory somewhere. I believe that most of the points I have to make apply equally well to either sort of accelerator.

In the interest of space, I am ignoring geometry acceleration in the rest of this paper. 3D systems spend a lot of time in floating point math code and special purpose hardware can speed this up tremendously. Similarly, geometry acceleration helps for imaging primitives like rotation and convolution. Aside from the performance gain of having more floating point hardware to throw at a problem, many graphics accelerators tightly couple the geometry accelerator and the drawing accelerator (or rendering engine, as it's also called). Not having to move data over the system bus improves performance and frees the bus for moving other data. This leaves more cycles for the user's application to generate the next set of work for the graphics accelerator.

---

[2] Page mode access to RAM provides noticeable gain over strict random access times. Nevertheless, the degradation is noticeable with large areas.

Optimization Principles

Optimize What People Notice

No one cares if your server has low overhead per request or even how many polylines you can render in a second. They care if their application runs fast. What you're trying to optimize is the performance of their application. You only need to speed up the parts of the server that they use a lot and care about. Users care about background repaint, text, copy area, and zero width lines. I've found that users of CAD software care about stippled rectangles. And everyone will complain if the server can't tile the root window quickly. But don't bother to speed up your wide dashed stippled arcs. So set your priorities well and optimize what people notice. (However, from personal experience I can tell you that some one who receives a preliminary release of your server will always care deeply about the thing that you just hadn't gotten around to yet.)

Optimize the System As a Whole

Another useful principle is to optimize the performance of the whole system, both in the large scale and in the small. In the large scale, you want to be sure to leave CPU cycles for the client application to use. Even benchmark programs will suffer if they get no CPU cycles. Usually, an even mix of cycles between server and client will run faster than bursts of one and then the other. Designing your server to balance cycles between the server and the client is an example of large scale holistic optimization.[3] On the small scale, if the graphics hardware hogs too many of the system resources, especially the data buses, it may starve out other components leading to slower overall performance. Slowing down the graphics engine may speed up the system. So be careful not to fall into the trap of greedy local optimizations degrading global performance.

Know When to Stop Optimizing

Know the limitations of your hardware and remember that you can't optimize to run faster than your hardware can. You can waste a great deal of time worrying about it, but it just doesn't help. If you are working with new hardware, and you find yourself up against a performance wall, go back and make sure that you've accurately estimated the potential performance.

Remember also that the 90-10 rule applies here. You can get 90 percent of the performance in 10 percent of the time. If you want that last 10 percent, it will take nine times as long to get it. If you have a short time to market, you may have to trade off that last little bit against some other optimization.

Finally, remember that your work has a limited lifespan anyway. The time you spend optimizing may be eating out of that total time. If your product is only state of the art for 18 months, you don't want to slip your schedule by 6 months to get those last optimizations finely tuned. It would be much better to put out the product at 90 percent of its theoretical performance rate and move onto the next graphics accelerator. You need to strike a balance between the desire for perfection and the desire to satisfy customers.

Application of Optimization Principles

Before we decided on most the optimizations discussed below, we ran a benchmark suite (x11perf) and several representative applications. These gave us a good idea of where we had performance problems. We also considered the theoretical maximum performance to see where we fell short and by how much. This lead us to target areas of optimization. Some of these were fairly generic goals like speeding up the transport mechanism; some were quite specific like tiling the root window faster. Having actual, measured, performance data gave us both target areas to optimize and a metric to measure our progress.

---

[3] This may be a new nadir in California high tech babble.